

PUNTAS 900 PARA ESTACIONES HAKKO 936

| | |
|--------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------|
| <p>1.2 mm (.047) ← 17 mm → (.670)</p> <p>900M-T-1.2D</p> | Shape: Chisel Size: Medium Fits 900M, 907, 913 irons Use with 926, 927, 928, 936, 937, 702, 703, 703B |
| <p>1.6 mm (.063) ← 17 mm → (.670)</p> <p>900M-T-1.6D</p> | Shape: Chisel Size: Medium Fits 900M, 907, 913 irons Use with 926, 927, 928, 936, 937, 702, 703, 703B |
| <p>2.4 mm (.095) ← 17 mm → (.670)</p> <p>900M-T-2.4D</p> | Shape: Chisel Size: Medium Fits 900M, 907, 913 irons Use with 926, 927, 928, 936, 937, 702, 703, 703B |
| <p>3.2 mm (.126) ← 17 mm → (.670)</p> <p>900M-T-3.2D</p> | Shape: Chisel Size: Medium Fits 900M, 907, 913 irons Use with 926, 927, 928, 936, 937, 702, 703, 703B |
| <p>.5r (.020) ← 17 mm → (.670)</p> <p>900M-T-B</p> | Shape: Conical Size: Medium Fits 900M, 907, 913 irons Use with 926, 927, 928, 936, 937, 702, 703, 703B |
| <p>.2r (.008) ← 17 mm → (.670)</p> <p>900M-T-I</p> | Shape: Conical Size: Medium Fits 900M, 907, 913 irons Use with 926, 927, 928, 936, 937, 702, 703, 703B |
| <p>.2r (.008) ← 25 mm → (.984)</p> <p>900M-T-LB</p> | Shape: Long Conical Size: Medium Fits 900M, 907, 913 irons Use with 926, 927, 928, 936, 937, 702, 703, 703B |
| <p>.2r (.008) ← 17 mm → (.670)</p> <p>900S-T-I</p> | Shape: Conical Size: Small Fits 900S (for Micro soldering) Use with 926, 927, 928, 936, 937, 702, 703, 703B |
| <p>1.2 mm (.047) ← 17 mm → (.670)</p> <p>900S-T-1.2D</p> | Shape: Chisel Size: Small Fits 900S (for Micro soldering) Use with 926, 927, 928, 936, 937, 702, 703, 703B |